

/ Marley MCW Cooling Tower /

User Manual 06-1310C



Contents

Note

This manual contains vital information for the proper installation and operation of your cooling tower. Carefully read the manual before installation or operation of the tower and follow all instructions. Save this manual for future reference.

| | |
|--------------------------------------|----|
| Tower Location | 5 |
| Tower Shipment..... | 6 |
| Receiving Tower | 6 |
| Hoisting Tower..... | 6 |
| Tower Installation..... | 7 |
| Tower Start-Up | 11 |
| Tower Operation..... | 13 |
| Wintertime Operation..... | 15 |
| Water Treatment and Blowdown..... | 16 |
| Cooling Tower Cleaning..... | 18 |
| Schedule of Tower Maintenance | 20 |
| Seasonal Shutdown Instructions | 22 |
| Prolonged Shutdown | 23 |
| Maintenance Schedule | 25 |
| Troubleshooting..... | 26 |
| Additional Information | 28 |

The following defined terms are used throughout this manual to bring attention to the presence of hazards of various risk levels, or to important information concerning the life of the product.

⚠ Warning

Indicates presence of a hazard which can cause severe personal injury, death or substantial property damage if ignored.

⚠ Caution

Indicates presence of a hazard which will or can cause personal injury or property damage if ignored.

Note

Indicates special instructions on installation, operation or maintenance which are important but not related to personal injury hazards.

Preparation

The Marley MCW cooling tower purchased for this installation represents the current state of the art in counterflow, forced draft cooling tower design. Thermally and operationally, it is the most efficient cooling tower of its class. These instructions—as well as those offered separately on motors, fans, float valves, etc.—are intended to assure that the tower serves you properly for the maximum possible time. Since product warrantability may well depend upon your actions, please read these instructions thoroughly prior to operation.

If you have questions about the operation and/or maintenance of this tower, and you don't find the answers in this manual, please contact your Marley sales representative. When writing for information, or when ordering parts, please mention tower serial number shown on the nameplate located on the access door.

Safety First

The location and orientation of the cooling tower can affect the safety of those responsible for installing, operating or maintaining the tower. However, since SPX Cooling Technologies does not determine the location or orientation of the tower, we cannot be responsible for addressing those safety issues that are affected by the tower's location or orientation.

⚠ Warning

The following safety issues should be considered by those responsible for designing the tower installation.

- ***access to and from maintenance access doors***
- ***the possible need for ladders (either portable or permanent) to gain access to the discharge level or maintenance access doors***
- ***the possible need for external access platforms***
- ***potential access problems due to obstructions surrounding the tower***
- ***lockout of mechanical equipment***
- ***the possible need for safety cages around ladders***
- ***the need to avoid exposing maintenance personnel to the potentially unsafe environment inside the tower.***

Those are only some of the safety issues that may arise in the design process. SPX strongly recommends that you consult a safety engineer to be sure that all safety considerations have been addressed.

Preparation

Several options are available that may assist you in addressing some of these personnel safety concerns, including:

- top of tower access platform with handrail system around the perimeter of the platform with a ladder for access to the platform
- ladder extensions (used where the base of the tower is elevated)
- safety cages for fan deck ladders
- distribution level access platform with handrail system around the perimeter of the platform with a ladder for access to the platform
- access door platform with handrail system around the perimeter of the platform with a ladder for access to the platform

Tower Location

Space available around the tower should be as generous as possible to promote ease of maintenance—and to permit freedom of airflow into and through the tower. If you have questions about the adequacy of the available space and the intended configuration of the tower, please contact your Marley sales representative for guidance.

Prepare a stable, level support foundation for the tower, utilizing weight, wind load, and dimensional information appearing on appropriate Marley submittal drawings. Supports must be level to insure proper operation of the tower.

Warning

The cooling tower must be located at such distance and direction to avoid the possibility of contaminated tower discharge air being drawn into building fresh air intake ducts. The purchaser should obtain the services of a Licensed Professional Engineer or Registered Architect to certify that the location of the tower is in compliance with applicable air pollution, fire, and clean air codes.

Receiving and Hoisting

Tower Shipment

Unless otherwise specified, MCW towers ship by truck (on flat bed trailers), which lets you receive, hoist, and install the tower in one continuous operation. Single-cell towers ship on one truck. Multicell towers, depending on their size, may require more than one truck.

Responsibility for the condition of the tower upon its arrival belongs to the trucker—as does the coordination of multiple shipments, if required.

Receiving Tower

Prior to unloading the tower from the delivering carrier, inspect the shipment for evidence of damage in transit. If damage is apparent, note the freight bill accordingly. This will support your future recovery claim.

Find and remove the installation instruction drawings and bills of material located in a plastic bag in the cold water basin. This information should be kept for future reference and maintenance purposes.

Hoisting Tower

All MCW models consist of two modules per cell. The upper module includes eye bolts at the top corners. Hoisting clips on the lower module are attached to the horizontal cross channels. A **Hoisting-Installation** label which has hoisting dimensional information is located on the side casing near the tower centerline. Remove tower from the carrier and hoist into place according to the instructions on the label.

⚠ Caution

MCW upper and lower modules must be hoisted and set separately. Do not preassemble modules prior to hoisting.

⚠ Warning

Hoisting clips are provided for ease of unloading and positioning tower. For overhead lifts or where additional safety is required, safety slings should also be placed under the tower. Under no circumstances should you combine the top and bottom modules of modular models and attempt to hoist them at the same time by utilizing the hoisting clips alone!

Installation

Note

Tower Installation

These installation instructions are intended to help you prepare before your tower arrives. If discrepancies exist between these instructions and those shipped with the tower, the instructions shipped with the tower will govern.

1. Prior to placement of the tower, confirm that the supporting platform is level, and that the anchor bolt holes are correctly located in accordance with Marley drawings.
2. Place the bottom module on your prepared supports, aligning anchor bolt holes with those in your supporting steel. Make sure that the orientation agrees with your intended piping arrangement. Attach tower to supporting steel with four 3/8" diameter bolts and flat washers (by others). Position flat washers between the bolt head and the tower basin flange.
3. Before setting top module in place on bottom module, clean any debris from the underside of the top module fill, skid and beams and from the top of the bottom module. Apply the mastic sealing strip supplied with the tower according to the **"MCW Field Installation Manual" Assembly Instructions**. Place top module on the top peripheral bearing surface of bottom module, aligning mating holes as it is set in place. Attach top module to bottom module with fasteners provided according to **"MCW Field Installation Manual" Assembly Instructions**.
4. Attach your cold water supply piping to the cold water basin outlet connection in accordance with drawing instructions, utilizing gaskets provided.

⚠ Caution

Do not support your pipe from the tower or outlet connection—support it externally.

5. Attach makeup water supply piping to appropriately-sized float valve connection located in cold water basin side wall. Install the drain and overflow according to the **"MCW Field Installation Manual" Assembly Instructions**. If you wish to pipe overflow and drain water to a remote discharge point, make those connections at this time also.
6. Attach your warm water return piping to the inlet connections of the tower.

Installation

Note

Fasteners and components provided by others that are to be attached to the tower must be compatible with the cooling tower materials—i.e. fasteners in a stainless steel cold water basin must be stainless steel.

⚠ Caution

Do not support your pipe from the tower or inlet connection—support it externally.

7. Wire motor in accordance with wiring diagram.

⚠ Warning

For maintenance/safety purposes, SPX recommends a lockout type disconnect switch for all mechanical equipment. In addition to a disconnect switch, the motor should be wired to main power supply through short circuit protection, and a magnetic starter with overload protection.

Motor Wiring

Wire motor leads as shown on the motor nameplate matching the supply voltage. Do not deviate from the motor nameplate wiring.

Either of following symbols may be shown on the motor nameplate – Δ , $\Delta \Delta$, Y, or YY. These symbols represent how the motor is constructed on the inside and in no way have anything to do with a Delta or Wye electrical distribution system serving the motor.

When using a starter:

- Set motor overload protection to 110% of motor nameplate amps. This setting allows the fan motor to operate during cooler weather. During cooler weather it is common for the motor to draw 6 to 10% higher than nameplate amps. High amps are common during tower commissioning when the tower is dry and the ambient air temperature is cool.

Note

Do not start the motor more than four to five times per hour. Short cycling the tower will cause fuses, breakers or O.L.s to operate and will decrease motor life.

When using a two-speed starter:

- Motor rotation must be the same at slow speed and high speed.
- Single winding motor requires a starter with a shorting contactor.

Installation

- Two-winding motor requires a starter with out a shorting contactor.
- All two-speed starters must have a 20 second time delay relay when switching from high speed to low speed.

Note

Do not start the motor more than four to five times per hour (each low speed start and each high speed start count as one start).

When using a VFD:

Note

Before beginning, ensure that the motor is rated for “Inverter Duty” per NEMA MG-1, part 31.

- Set the VFD solid state overload protection to 119% of motor nameplate amps and set “maximum current parameter” in the VFD to motor nameplate amps. “Maximum current parameter” will reduce fan speed and limit amp draw to nameplate amps during cold weather operation. If furnished with a mechanical O.L. set this at 110% over motor nameplate amps.
- Motor rotation must be the same in both VFD mode and By-pass mode.
- If cable distance between the VFD and motor is greater than 100 feet a DV/DT output filter is recommended to avoid damage to the motor. 100 feet distance is based on our field experience, the VFD manufacture may state different distances and distance does vary depending on the VFD manufacture.
- Program the VFD for variable torque output. Flux vector and constant torque modes may damage the gearbox.
- Do not start and stop the motor using the safety switch at the motor. If the drive is being commanded to run and the load side is cycled ON and OFF with the safety switch this may damage the VFD.

Using a VFD in cooling applications has advantages over traditional single or two speed motor control. A VFD can reduce the cost of electrical energy being used and provide better temperature control. In addition, it reduces the mechanical and electrical stress on the motor and mechanical equipment. Electrical savings can be large during periods of low ambient temperature when the cooling requirement can be satisfied at reduced speeds. To benefit from these advantages, it is important that the drive be installed correctly.

Marley supplies VFD and VFD controls specifically designed for our cooling products. If you have purchased a Marley VFD and/or controls package,



Installation

please follow the instructions in the *User Manual* for that system. Most VFD problems can be avoided by purchasing the Marley drive system. If you are installing a VFD other than the Marley drive, please refer to that drives installation manual.

⚠ Warning

Improper use of a VFD may cause damage to equipment or personal injury. Failure to correctly install the VFD drive will automatically void all warranties associated with the motor and any equipment that is either electrically or mechanically (directly) attached to the VFD drive system. The length of this warranty avoidance will be contingent on properly installing the VFD system and repairing any damage that may have occurred during its operation. SPX Cooling Technologies does not assume responsibility for any technical support or damages for problems associate with non-Marley brand VFD systems.

⚠ Warning

Changing the operational fan speed from the factory settings could cause the fan to operate in an unstable region which may result in damage to the equipment and possible injury.

Mechanical Equipment:

⚠ Warning

Always shut off electrical power to the tower fan motor prior to performing any maintenance on the tower. Any electrical switches should be locked out and tagged out to prevent others from turning the power back on.

1. Spin the fan manually and observe the action of the sheaves and belts to be sure that the motor is properly aligned with the fan sheave. See Belt Tensioning and Sheave Alignment on pages 19 and 20.
2. Momentarily bump (energize) the motor and observe rotation of the fan. The fan should rotate in a counterclockwise direction when viewed from the fan inlet side from the motor end. If rotation is backwards, shut off the fan and reverse two of the three primary leads supplying power to the motor.

⚠ Caution

If tower is equipped with a two-speed motor, check for proper rotation at both speeds. Check also to see that starter is equipped with a 20 second time delay which prevents direct switching from high speed to low speed.

Installation

3. Check the torque on the fan and motor sheave after 10 to 60 hours of operation. See Bushing Fastener Torque Values on page 20.

Note

If the water supply system is not being operated—or if there is no heat load on the system—motor amps read at this time may indicate an apparent overload of as much as 10–20%. This is because of the increased density of unheated air flowing through the fan. Determination of an accurate motor load should await the application of the design heat load.

Tower Start-Up

Among other sources, outbreaks of Legionnaires' Disease have reportedly been traced to cooling towers. Maintenance and water treatment procedures that prevent amplification and dissemination of Legionella and other airborne bacteria should be formulated and implemented BEFORE systems are operated and continued regularly thereafter to avoid the risk of sickness or death.

⚠ Warning

Water System:

1. New installations should be cleaned and treated with biocides by a water treatment expert before startup.
2. Remove any and all accumulated debris from tower. Pay particular attention to inside areas of cold water basin, and drift eliminators. Make sure that cold water suction screens are clear and properly installed.
3. Fill the water system to an approximate depth of 13" in the cold water basin. This is the recommended operating water level. Adjust the float valve so that it is 75% open at that level. Continue filling the system until the water reaches a level approximately $\frac{1}{8}$ " below the lip of the overflow.
4. Completely open all hot water valves. Start your pump(s) and observe system operation. Since the water system external to the tower will have been filled only to the level achieved in the cold water basin, a certain amount of "pump-down" of the basin water level will occur before water completes the circuit and begins to fall from the fill. The amount of initial pump-down may be insufficient to cause the float valve to open. However, you can check its operation by pressing down on the operating lever to which the stem of the float valve is attached.

Installation

Some trial and error adjustment of the float valve may be required to balance the makeup water with tower operation. Ideally, the float valve setting will be such that no water is wasted through the overflow at pump shutdown. However, the water level after pump start-up **must** be deep enough to assure positive pump suction.

5. Continue pump operation for about 15 minutes, after which it is recommended that the water system be drained, flushed, and refilled.
6. While operating the condensing water pump(s) and prior to operating the cooling tower fan, execute one of the two alternative biocidal treatment programs described in the following:
 - Resume treatment with the biocide which had been used prior to shutdown. Utilize the services of the water treatment supplier. Maintain the maximum recommended biocide residual (for the specific biocide) for a sufficient period of time (residual and time will vary with the biocide) to bring the system under good biological control
 - or**
 - Treat the system with sodium hypochlorite to a level of 4 to 5 mg/L free chlorine residual at a pH of 7.0 to 7.6. The chlorine residual must be held at 4 to 5 mg/L for six hours, measurable with standard commercial water test kits.

If the cooling tower has been in operation and then shut down for a duration of time and not drained, perform one of the two previous biocidal treatment programs directly to the cooling water storage vessel (cooling tower sump, drain down tank, etc.) without circulating stagnant water over the cooling tower fill or operating the cooling tower fan.

After biocidal pretreatment has been successfully completed, cooling water may be circulated over the tower fill with the fan off.

When biocidal treatment has been maintained at a satisfactory level for at least six hours, the fan may be turned on and the system returned to service. Resume the standard water treatment program, including biocidal treatment.

Operation

Tower Operation

General:

The cold water temperature obtained from an operating cooling tower will vary with the following influences:

1. **Heat load:** With the fan in full operation, if the heat load increases, the cold water temperature will rise. If the heat load reduces, the cold water temperature will reduce.

Note that the number of degrees (“range”) through which the tower cools the water is established by the system heat load and the amount of water being circulated, in accordance with the following formula:

$$\text{Range} - ^\circ\text{F} = \frac{\text{Heat Load (Btu/hr)}}{\text{GPM} \times 500}$$

The cooling tower establishes only the cold water temperature attainable under any operating circumstance.

2. **Air wet-bulb temperature:** Cold water temperature will also vary with the wet-bulb temperature of the air entering the louvered faces of the tower. Reduced wet-bulb temperatures will result in colder water temperatures. However, the cold water temperature will not vary to the same extent as the wet-bulb. For example, a 20°F reduction in wet-bulb may result in only a 15°F reduction in cold water temperature.
3. **Water flow rate:** Increasing the water flow rate (GPM) will cause a slight elevation in cold water temperature, while reducing the water flow rate will cause the cold water temperature to decrease slightly. However, at a given heat load (see formula), water flow reductions also cause an increase in the incoming hot water temperature. Use care to prevent the hot water from exceeding 125°F in order to prevent damage to the tower components.
4. **Air flow rate:** Reducing air flow through the tower causes the cold water temperature to rise. This is the approved method by which to control leaving water temperature.

If your tower is equipped with a single-speed motor, the motor may be shut off when the water temperature becomes too cold. This will cause the water temperature to rise. When the water temperature then becomes too warm for your process, the motor can be restarted.



Operation

Fan cycling limits:

Note

Considering the normal fan and motor sizes utilized on MCW towers, anticipate that approximately 4 to 5 starts per hour are allowable.

If your tower is equipped with a two-speed motor, greater opportunity for temperature control is afforded you. When the water temperature becomes too cold, switching the fan to half-speed will cause the cold water temperature to rise—stabilizing at a temperature a few degrees higher than before. With a further reduction in water temperature, the fan may be cycled alternately from half-speed to off.

Note

Do not start the motor more than four to five times per hour (each low speed start and each high speed start count as one start).

If your tower consists of two or more cells, cycling of motors may be shared between cells, increasing your steps of operation accordingly.

⚠ Caution

Multiple fan motors serving a single fill section must be cycled simultaneously. This applies to models 901146 thru 901157, 901556 thru 901558, 901756 thru 901758 and 901956 thru 901959 MCW models.

Multicell towers equipped with two-speed motors will maximize energy savings and minimize sound levels if fans are staged so that all fans are brought up to low speed before any fan goes to high speed.

For greater insight on cold water temperature control, please read **“Cooling Tower Energy and its Management”**, *Technical Report #H-001-A*, available spxcooling.com.

Operation

Wintertime Operation:

During operation in subfreezing weather, the opportunity exists for ice to form in the colder regions of the tower. Your primary concern is to prevent the formation of destructive ice on the cooling tower fill. Your understanding of cold weather operation will be enhanced if you read *Marley Technical Report H-003* "Operating Cooling Towers in Freezing Weather", augmented by the following guidelines:

1. Do not allow the tower's leaving water temperature to drop below a minimum allowable level—about 35°F—established as follows:

During the coldest days of the first winter of operation, observe whether any ice is forming, particularly near the bottom of the fill. If hard ice is present, you must increase the allowable cold water temperature. If the coldest possible water is beneficial to your process, ice of a mushy consistency can be tolerated—but routine periodic observation is advisable.

Caution

If the minimum allowable cold water temperature is established at or near minimum heat load, it should be safe for all operating conditions.

Having established the minimum allowable cold water temperature, maintaining that temperature can be accomplished by fan manipulation, as outlined in **Tower Operation: Item 4** on page 13. However, in towers of more than one cell, the limiting temperature established applies to the water temperature of the cell or cells operating at the highest fan speed—not necessarily the net cold water temperature produced by the entire tower.

2. A fan operating in a forced-draft tower is subject to the risk of freezing. Icing is a particular danger as this can form not only on the fan blades, but also the inlet guard. Ice particles can be thrown off and cause severe damage. The fan casing should be checked so that any water entering it (either from the tower or external sources) can drain away. If water is allowed to collect in the fan casing, the fan could be frozen into place. This could result in damage to the drive system if starting were attempted



Operation

3. As cold air enters the tower, it causes the falling water to be drawn inward. Thus, under fan operation, the lower periphery of the tower structure remain partly dry, seeing only random splashing from within the tower—plus normal atmospheric moisture from the entering air. Such lightly wetted areas are most subject to freezing.

Although ice is unlikely to cause structural damage, it may build up sufficiently to restrict the free flow of air. This will have the effect of reducing the tower's thermal performance efficiency. When excessive ice forms, stop the fan for a few minutes. With the fan off, the action of the spray system will cause a slight downward movement of air through the fill and deice the fill.

Intermittent Wintertime Operation:

If periods of shutdown (nights, weekends, etc.) occur during freezing weather, measures must be taken to prevent the water in the cold water basin—and all exposed pipework—from freezing. Several methods are used to combat this, including automatic basin heater systems available from Marley.

⚠ Caution

Unless some means of freeze prevention is incorporated into your system, the tower basin and exposed pipework should be drained at the beginning of each wintertime shutdown period.

⚠ Warning

If tower basin is drained, verify that all basin heaters have been shut off either by automatic cutoff or disconnect switch.

It is recommended that you discuss your freeze prevention options with your local Marley sales representative.

Water Treatment and Blowdown

Maintaining Water Quality:

The steel used in MCW towers has been galvanized with a heavy zinc coating averaging 2.0 mils in thickness. The MCW stainless steel option is even more corrosion resistant than galvanized steel in certain environments. Other materials used (PVC fill, drift eliminators, and louvers, etc.) are selected to offer maximum service life in a “normal” cooling tower environment, defined as follows:

Operation

Circulating water with a pH between 6.5 and 8; a chloride content (as NaCl) below 500 mg/L; a sulfate content (SO₄) below 250 mg/L; total alkalinity (as CaCO₃) below 500 mg/L; calcium hardness (as CaCO₃) above 50 mg/L; a maximum inlet water temperature not to exceed 125°F; no significant contamination with unusual chemicals or foreign substances; and adequate water treatment to minimize scaling.

- Startup Conditions: The water conditions during the initial tower operation are crucial in preventing premature corrosion of galvanized steel (white rust). For at least the first eight weeks of operation, pH should be controlled between 6.5 and 8.0 with hardness and alkalinity levels between 100 and 300 mg/L (expressed as CaCO₃).
- Chlorine (if used) shall be added intermittently, with a free residual not to exceed 1 mg/L—maintained for short periods. Excessive chlorine levels may deteriorate sealants and other materials of construction.
- An atmosphere surrounding the tower no worse than “moderate industrial”, where rainfall and fog are no more than slightly acid, and they do not contain significant chlorides or hydrogen sulfide (H₂S).
- Many proprietary chemicals exist for control of scale, corrosion, and biological growth and should be used prudently. Also, combinations of chemicals may cause reactions which reduce treatment effectiveness, and certain chemicals such as surfactants, biodispersants and antifoams may increase drift rate.

Note

Unless you purchased a stainless steel MCW, the structure of your MCW tower consists primarily of galvanized steel, therefore your water treatment program must be compatible with zinc. In working with your water treatment supplier, it is important that you recognize the potential effects on zinc of the specific treatment program you choose.

Maintenance

⚠ Warning

Cooling Tower Cleaning:

Any evaporative-type cooling tower must be thoroughly cleaned on a regular basis to minimize the growth of bacteria, including *Legionella Pneumophila*, to avoid the risk of sickness or death. Service personnel must wear proper personal protective equipment during decontamination. Do NOT attempt any service unless the fan motor is locked out.

Operators of evaporative cooling equipment, such as water cooling towers, should follow maintenance programs which will reduce to an absolute minimum the opportunity for bacteriological contamination. Public Health Service officials have recommended that “good housekeeping” procedures be followed, such as: regular inspections for concentrations of dirt, scale, and algae; periodic flushing and cleaning; and the following of a complete water treatment program including biocidal treatment.

The visual inspection should take place at least once a week during the operating season. The periodic flushing and cleaning should be done before and after each cooling season, but in any event at least twice a year. The drift eliminators, and easily accessible fill surfaces should be flushed by use of a moderate-pressure water nozzle, being careful not to cause physical damage. A reliable water treatment program should be installed and maintained. Filtration devices may be employed to reduce the suspended solids concentrations, thus increasing the effectiveness of the water treatment program. See Tower Startup instructions on page 11.

Blowdown:

A cooling tower cools water by continuously causing a portion of it to evaporate. Although the water lost by evaporation is replenished by the makeup system, it exits the tower as pure water—leaving behind its burden of dissolved solids to concentrate in the remaining water. Given no means of control, this increasing concentration of contaminants can reach a very high level.

In order to achieve water quality which is acceptable to the cooling tower (as well as the remainder of your circulating water system), the selected water treatment company must work from a relatively constant level of concentrations. This stabilization of contaminant concentrations is usually accomplished by blowdown, which is the constant discharge of a portion of the circulating water to waste. As a rule, acceptable levels on which to base a treatment

Maintenance

schedule will be in the range of 2-4 concentrations. The following table shows the minimum amount of blowdown (percent of flow) required to maintain different concentrations with various cooling ranges*:

| Cooling Range | Number of Concentrations | | | | | | |
|---------------|--------------------------|------|------|------|------|------|------|
| | 1.5X | 2.0X | 2.5X | 3.0X | 4.0X | 5.0X | 6.0X |
| 5°F | .78 | .38 | .25 | .18 | .11 | .08 | .06 |
| 10°F | 1.58 | .78 | .51 | .38 | .25 | .18 | .14 |
| 15°F | 2.38 | 1.18 | .78 | .58 | .38 | .28 | .22 |
| 20°F | 3.18 | 1.58 | 1.05 | .78 | .51 | .38 | .30 |
| 25°F | 3.98 | 1.98 | 1.32 | .98 | .64 | .48 | .38 |

Multipliers are based on drift of 0.02% of the circulating water rate.

* Range = Difference between hot water temperature coming to tower and cold water temperature leaving tower.

EXAMPLE: 700 GPM circulating rate, 18°F cooling range. To maintain 4 concentrations, the required blowdown is 0.458% or .00458 times 700 GPM, which is 3.2 GPM.

If tower is operated at 4 concentrations, circulating water will contain four times as much dissolved solid as the makeup water, assuming none of the solids form scale or are otherwise removed from the system.

Note

When water treatment chemicals are added, they should not be introduced into the circulating water system via the cold water basin of the cooling tower. Water velocities are lowest at that point, which results in inadequate mixing.

Belt Tensioning

The belts are adjusted by means of a hinged base with tensioning bolts accessible through the access panel/fan guards. Check tension frequently during the first 24-48 hours of run-in operation. To properly adjust the belt tension, position the fan motor so that moderate pressure on the belt midway between the sheaves will produce a ½" deflection. Overtensioning shortens belt and bearing life. Keep belts free from foreign material which may cause slipping. Never apply belt dressing as this will damage the belt and cause early failure. A Dodge® V-Belt Tension Tester is an alternate method for tensioning V-belts. Check with you local belt supplier.

Maintenance

Sheave Alignment

- The motor sheave is to be positioned as close as possible to the motor in order to minimize torque on the motor bushings.
- The motor and fan sheaves may have grooves that are not used. The bottom surface of the motor and fan sheaves must be aligned within $\frac{1}{8}$ " of each other and level within $\frac{1}{2}^\circ$ ($\frac{1}{8}$ " in 12") in order to not adversely affect belt and sheave life.
- Alignment can be achieved by placing a straight edge across the top of the sheaves making sure that it is level and measuring down to the bottom surface of both sheaves at four points.
- The belt is to be located in the inboard set of grooves closest to the bearing.

Bushing Fastener Torque Values

| Bushing | Fastener | Torque ft·lb _f |
|---------|---------------------|---------------------------|
| SH | $\frac{1}{4}$ - 20 | 6 |
| SDS | $\frac{1}{4}$ - 20 | 6 |
| SD | $\frac{1}{4}$ - 20 | 6 |
| SK | $\frac{5}{16}$ - 18 | 13 |
| SF | $\frac{3}{8}$ - 16 | 22 |
| E | $\frac{1}{2}$ - 13 | 35 |
| F | $\frac{5}{16}$ - 12 | 65 |

Schedule of Tower Maintenance

Some maintenance procedures may require maintenance personnel to enter the tower.

Warning

The purchaser or owner is responsible for providing a safe method for entering or exiting the access door.

Included with this instruction packet are separate User Manuals on each major operating component of the tower, and it is recommended that you read them thoroughly. Where discrepancies may exist, the separate User Manuals will take precedence.

Maintenance

The following is recommended as a minimum routine of scheduled maintenance:

⚠ Warning

Always shut off electrical power to the tower fan motor prior to performing any inspections that may involve physical contact with the mechanical or electrical equipment in or on the tower. Lock out and tag out any electrical switches to prevent others from turning the power back on. Service personnel must wear proper personal protective clothing and equipment.

Weekly: Inspect for bacterial growth and general operation conditions. Bacterial growth should be reported to your water treatment expert for immediate attention.

Monthly (Weekly at start up): Observe, touch, and listen to the tower. Become accustomed to its normal appearance, sound, and level of vibration. Abnormal aspects relating to the rotating equipment should be considered reason to shut down the tower until the problem can be located and corrected. Observe operation of the motor and fan. Become familiar with the normal operating temperature of the motor, as well as the sight and sound of all components as a whole.

Inspect drift eliminators and basin trash screens and remove any debris or scale which may have accumulated. Replace any damaged or worn out components. Use of high-pressure water may damage the eliminator material.

Observe operation of the float valve. Depress the operating lever to make sure that the valve is operating freely. Inspect the suction screen for plugging. Remove any debris that may have accumulated.

Check for any buildup of silt on the floor of the cold water basin. Mentally make note of the amount, if any, so future inspections will enable you to determine the rate at which it is forming.

Every 3 months: Lubricate fan shaft bearings. While rotating equipment by hand, grease the bearings until a bead forms around the seals—a maximum charge of 0.40 ounces is recommended. Mobil SHC 460 grease is recommended.

Semi-Annually: Check the belt tension and condition.

Clean and disinfect cooling tower with biocides. Systems with biofouling, high general bacterial counts, or positive cultures of legionella may require additional cleaning. Refer to “**Cooling Tower Cleaning**” section—page 18. Consult your water treatment expert as to prudent biological evaluation testing.



Maintenance

Annually: Relubricate motor according to the manufacturer's instructions.

Check to see that all bolts are tight in the fan and mechanical equipment region. Refer to Component User Manuals for torque values.

Inspect the tower thoroughly, making maximum use of instructions given in the separate user manuals. Check structural bolted connections and tighten as required. Make preventive maintenance repairs as necessary.

Seasonal Shutdown Instructions

When the system is to be shut down for an extended period of time, it is recommended that the entire system (cooling tower, system piping, heat exchangers, etc.) be drained. Leave the basin drains open.

During shutdown, clean the tower (see Warning, page 18) and make any necessary repairs. Pay particular attention to mechanical equipment supports.

Following each year's shutdown and cleaning, inspect the tower's metal surfaces for evidence of the need to apply a protective coating. Do not misinterpret grime—and transient rust from the piping system—as a need to have the tower painted. If relatively bright metal can be exposed by cleaning, consider that the galvanizing has remained effective. Unless there is evidence of a generalized failure of the galvanizing, localized touch-up should be all that is required.

Note

To the extent that the galvanizing (zinc coating) still exists, paint will not adhere to it readily. Contact the manufacturer of the coating you intend to use for instructions.

Maintenance

Tower framework: Check structural bolted connections and tighten as required.

Fans: Check fan assembly bolting and tighten as required. Use torque values prescribed in the Fan User Manual.

Fans shaft bearings: If equipped, lubricate fan shaft bearings at close of each operating season—see page 21.

Electric motors: Clean and lubricate motor at close of each operating season (refer to motor manufacturer's recommendations.) Check motor anchor bolts and tighten as required.

 **Caution**

Do not start motor before determining that there will be no interference with free rotation of the fan drive.

The motor should be operated for three hours at least once a month. This serves to dry out windings and re-lubricate bearing surfaces (refer to Marley **“Electric Motor User Manual”** *Manual 92-1475*).

At start of new operating season, make sure bearings are adequately lubricated before returning motor to service.

Prolonged Shutdown

If shutdown period is longer than seasonal, contact your Marley sales representative for additional information.

Maintenance

SPX Cooling Technologies Services

Our interest in your MCW cooling tower does not end with the sale. Having conceived, designed, and manufactured the most reliable and longest-lasting cooling tower of its class, we want to make sure that you gain the maximum possible benefit from its purchase.

Therefore, the following services are available which are intended to: assure the maximum possible service life under your operating conditions; tailor the operating characteristics to your specific needs; and maintain consistently optimum thermal performance capability. They are available by contacting your Marley sales representative.

Replacement parts: A complete stock of parts and components are maintained at one or more of the various Marley plants. In cases of emergency, they can normally be shipped within 24 hours—by air freight if necessary. However, you would obviously benefit from anticipating your need in advance, thus avoiding the cost of special handling.

Be sure to mention your tower serial number (from the tower nameplate) when ordering parts.

Periodic maintenance: You may wish to contract with SPX for regularly scheduled visits—for the purpose of inspecting and reporting your tower's condition—to make recommendations intended to prevent emergencies— and to perform maintenance considered outside the norm.

This service is not intended to replace the important function performed by your maintenance staff. Their attention assures the tower's routine operating performance, and is invaluable. However, we recognize the unusual manner in which a cooling tower performs its function—as well as the unique forces which act upon it—may be considerations which occasionally require the services of an expert technician.

Maintenance Schedule

| Maintenance Service | Monthly | Semi-annually | Seasonal Startup or Annually |
|---|-----------------|-----------------|------------------------------|
| Inspect General Condition and Operation | x | | x |
| Observe Operation of: | | | |
| Mechanical—motor, fan and drive mechanism | x | | x |
| Makeup valve (if equipped) | x | | x |
| Inspect for unusual noise or vibration | x | | x |
| Inspect and Clean: | | | |
| Air inlet | x | | x |
| PVC drift eliminators | x | | x |
| Distribution system and nozzles | x | | x |
| Collection basin | x | | x |
| Fan motor exterior | x | | x |
| Check: | | | |
| Collection water basin level | x | | x |
| Blowdown—adjust as required | x | | x |
| Belt drive: | | | |
| Fan shaft bearing lubrication (every 3 mo.) | | every 3 months | every 3 months |
| Check and tighten support fasteners | | | x |
| Check shaft, sheave and belt alignment | | | x |
| Check belt tension and condition | | x | x |
| Check sheave bushing fastener torque | | | x |
| Fan: | | | |
| Check and fan assembly fasteners | | | x |
| Motor: | | | |
| Lubricate (grease as required) | | | R |
| Check mounting bolts for tightness | | | x |
| Operate at least | 3 hours a month | 3 hours a month | 3 hours a month |
| Basin Heater (if equipped): | | | |
| Check for proper operation of temp/low water level sensor | | | x |
| Inspect/clean buildup of contaminant from sensor | | x | x |
| Structure: | | | |
| Inspect/tighten all fasteners | | x | x |
| Inspect and touch up all metal surfaces | | | x |

R – Refer to Component User Manual

Note: It is recommended at least weekly, that the general operation and condition be observed. Pay attention to any changes in sound or vibration that may signify a need for closer inspection.

Troubleshooting

| Trouble | Cause | Remedy |
|---------------------------------|---|--|
| Motor will not start | Power not available at motor terminals | Check power at starter. Correct any bad connections between the control apparatus and the motor. Check starter contacts and control circuit. Reset overloads, close contacts, reset tripped switches or replace failed control switches. If power is not on all leads at starter, make sure overload and short circuit devices are in proper condition |
| | Wrong connections | Check motor and control connections against wiring diagrams. |
| | Low voltage | Check nameplate voltage against power supply. Check voltage at motor terminals. |
| | Open circuit in motor winding | Check stator windings for open circuits. |
| | Motor or fan drive stuck | Disconnect motor from load and check motor and fan drive for cause of problem. |
| Unusual motor noise | Rotor defective | Look for broken bars or rings. |
| | Motor running single-phase | Check motor and attempt to start it. Motor will not start if single-phased. Check wiring, controls and motor. |
| | Motor leads connected incorrectly | Check motor connections against wiring diagram on motor. |
| | Bad bearings | Check lubrication. Replace bad bearings. |
| | Electrical unbalance | Check voltages and currents of all three lines. Correct if required. |
| | Air gap not uniform | Check and correct bracket fits or bearing. |
| Motor runs hot | Rotor unbalance | Rebalance |
| | Cooling fan hitting end belt guard | Reinstall or replace fan. |
| | Wrong voltage or unbalanced voltage | Check voltage and current of all three lines against nameplate values. |
| | Wrong motor RPM | Check nameplate against power supply. Check RPM of motor and drive ratio. |
| | Bearing overgreased | Remove bearing reliefs. Run motor up to speed to purge excessive grease. |
| | Wrong lubricant in bearings | Change to proper lubricant. See motor manufacturer's instructions. |
| | One phase open | Stop motor and attempt to start it. Motor will not start if single-phased. Check wiring, controls and motor. |
| | Poor ventilation | Clean motor and check ventilation openings. Allow ample ventilation around motor. |
| | Winding fault | Check with ohmmeter. |
| | Bent motor shaft | Straighten or replace shaft. |
| Motor does not come up to speed | Insufficient grease | Remove plugs and regrease bearings. |
| | Too frequent starting or speed changes | Limit cumulative accelerations time to a total of 30 seconds/hour. Set on/off or speed change set points farther apart. Consider installing a Marley VFD drive for fine temperature control. |
| | Deterioration of grease or foreign material in grease | Flush bearings and relubricate. |
| | Bearings damaged | Replace bearings. |
| | Voltage too low at motor terminals because of line drop | Check transformer and setting of taps. Use higher voltage on transformer terminals or reduce loads. Increase wire size or reduce inertia. |
| Wrong motor rotation | Broken rotor bars | Look for cracks near the rings. A new rotor may be required. Have motor service person check motor. |
| | Wrong sequence of phases | Switch any two of the three motor leads. |

Troubleshooting

| Trouble | Cause | Remedy |
|--|---|---|
| Unusual fan drive vibration | Loose bolts and cap screws | Tighten all bolts and cap screws on all mechanical equipment and supports. |
| | Worn fan shaft bearings.. | Check fan shaft endplay. Replace bearings as necessary. |
| | Unbalanced motor | Disconnect load and operate motor. If motor still vibrates, rebalance rotor. |
| Fan noise | Impeller rubbing inside of cylinder | Adjust fan impeller. Adjustment may need to be axial i.e. moving impeller along the shaft to centralize it between the cylinders or radial by repositioning bearing or bearings to get the impeller concentric within the inlets. |
| | Fan shaft bearing. | Grease bearings. |
| Belt squeal or chirping | Belt slipping | Adjust belt |
| Scale or foreign substance in circulating water system | Insufficient blowdown | See "Water Treatment" section of this manual. |
| | Water treatment deficiency | Consult competent water treating specialist. See "Water Treatment" section of this manual |
| Cold water temperature too warm. See "Tower Operation." | Entering wet bulb temperature is above design | Check to see if local heat sources are affecting cooling tower. See if surrounding structures are causing recirculation of tower discharge air. Discuss remedy with Marley representative. |
| | Design wet bulb temperature was too low. | May have to increase cooling tower size. Discuss remedy with Marley representative |
| | Actual process load greater than design | May have to increase cooling tower size. Discuss remedy with Marley representative |
| | Overpumping | Reduce water flow rate over cooling tower to design conditions. |
| Excessive drift exiting cooling tower | Cooling tower starved for air | Check motor current and voltage to be sure of correct contract horsepower. Clean fill and eliminators. Check to see if nearby structures or enclosing walls are obstructing normal airflow to cooling tower. Discuss remedy with Marley representative. |
| | Faulty drift elimination | Check to see that eliminators are clean, free of debris and installed correctly. Replace damaged or worn out eliminators panels. |
| Water leaking from fan scroll | Water level in tower too high | Adjust water level to correct height |
| | Multiple fan motors serving a single fill section not being cycled simultaneously | Ensure all fans are operating simultaneously and at the same speed |

Additional Information

Increased load requirements: MCW towers are designed so that cells of either equal or unequal capacity can be added in the future. This allows you to compensate for the load increases that normally occur with the replacement or addition of production equipment—and still retain continuity with respect to your cooling tower system.

Tower rebuilding: SPX Cooling Technologies routinely rebuilds and upgrades cooling towers of all materials and manufacture. If your tower ever reaches the limit of its service life, we recommend that you investigate the cost of rebuilding before you routinely order a new replacement tower.

Each MCW Class tower includes a document package containing general orientation drawings, **“MC Field Installation Manual”** *Assembly Instructions*, and tower component manuals. **These documents contain important information relating to safe installation and operation of the cooling tower.** Field installation is always required for fan guards, piping inlets and piping outlets. Some optional accessories, such as platforms, handrails, ladders and safety cages may also require field installation. If installation details are not covered in the **“MC Field Installation Manual”** a separate installation drawing or manual for each purchased option is included in the document package along with bills of material. If you have purchased an option and can't find the appropriate installation drawing, contact your local Marley sales representative before proceeding.

In addition to these specific documents, SPX publishes numerous technical reports including more detailed information on a variety of cooling tower operation and service topics. Electronic copies of these reports are available for download at spxcooling.com.

For complete parts and service assistance, contact the Marley sales representative in your area. If you need help locating the office nearest you, please phone 913 664 7400 or check the internet at spxcooling.com.

SPX[®]

COOLING TECHNOLOGIES

7401 WEST 129 STREET | OVERLAND PARK, KANSAS 66213 UNITED STATES | 913 664 7400 | spxcooling@spx.com | spxcooling.com

In the interest of technological progress, all products are subject to design and/or material change without notice.
©2009 SPX Cooling Technologies, Inc. | Printed in USA

M06-1310C